

***PROUDLY MADE IN USA AT AN ISO 9001 CERTIFIED FACILITY***

# **RX-2 CONCENTRATE**

**Directions:** Concrete surfaces to be treated must be free of foreign material and have an open pore texture. Smooth concrete must be sandblasted or acid etched. Concrete surfaces must be thoroughly saturated with clean water prior to application so as to aid the proper curing of the treatment and ensure the growth of the crystalline formation deep within the pores of the concrete. Remove excess surface water before the application. For brush application blend 5 parts RX-2 Concentrate with 2 parts clean water by volume (for spray application use 3 parts of water) and mix to a creamy consistency. Do not mix more material than can be applied in 20 minutes and do not add water once mix starts to harden. Apply RX-2 Concentrate with a semi-stiff nylon bristle brush, push broom (for large horizontal surfaces) or specialized spray equipment. The coating must be uniformly applied and should have a thickness of just under 1/16 in (1.25mm). When a second coat is required it should be applied after the first coat has reached an initial set but no later than 48 hours. RX-2 Concentrate cannot be applied in rain or when ambient temperature is below 40°F (4°C). A misty fog spray of clean water must be used to cure the treatment. Curing must begin as soon as the coating has sufficiently hardened so as not to be damaged by a fine spray. Under normal conditions it is sufficient to spray the treated surfaces three times a day for 2 to 3 days. In hot or arid climates spraying may be required more frequently. During the curing period the coating must be protected.

## **1. FIRST AID:**

**Eyes** – Flush with cool water for at least 15 minutes. Call a physician.

**Skin** - Wash thoroughly with soap and water. Call a physician.

**Ingestion** – Call a physician. Never give anything by mouth to an unconscious person.

**Inhalation** – If inhaled, remove to fresh air. If not breathing, give artificial respiration, preferably mouth to mouth. Call a physician.

**2. SPILL CONTROL:** Eliminate all ignition sources and keep public away. Recover free product with absorbent materials and dispose of in accordance with local, State and Federal Regulations. Keep product out of sewers and water courses.

**DANGER:** Keep out of reach of children and animals.

Always wear gloves and protective goggles when using this product.

HMIS: H=2, F=0, R=0, PP=X

**NET CONTENTS: 60 Pounds**

**3. PROTECTIVE EQUIPMENT:** Wear safety glasses or goggles and recommended protective gloves. If exposure exceeds TLV, Wear NIOSH/MSHA approved respirator.

**4. PRECAUTIONS:** Do not get in eyes, on skin or clothing. Do not take internally. Wash thoroughly after handling.

**5. GENERAL INSTRUCTIONS:** Before using this product read Material Safety Data Sheet (MSDS) which is available on website.

**Note: Emptied Container retains vapor or product residue.**

**DISCLAIMER:** The information contained herein is based on data available to us and is believed to be accurate. However, Stone Technologies, Corp makes no express or implied warranty of merchantability or fitness for a particular use. Handling, storage and use of this product by the buyer or user are beyond the control of Stone Technologies, Corp. Risks such as ineffectiveness or other unintended consequences resulting from but not limited to failure to follow label directions will be assumed by the buyer or user. In no case will seller be held liable for consequential, special or indirect damages resulting from the handling, storage or use of this product. VER 1/2015